

ASSEMBLY MANUAL

EASY 7 STEP ASSEMBLY:

1. CONNECT FLAPS WITH ROTOR.
2. PLACE THE ROTOR IN THE STRUCTURE HOLES.
3. PLACE THE GEAR.
4. CLOSE THE ROTOR SIDES
5. CONNECT THE BASE WITH THE STRUCTURE.
6. PLACE THE MOTOR IN POSITION
7. CLOSE THE FRONT CAP.

